Congratulations!

You are now the proud owner of an elna trolley! We are confident you will enjoy your carrier and it will provide years of service to you.

These comprehensive instructions were designed to guide you through the assembly process. Should you require any further assistance, don't hesitate to contact your elna dealer.

Assembly of side support frame

1. Locate zipper opening on bottom of side panel.



2. Insert steel frame into side panel as pictured. **REPEAT** this process for opposite side of bag.



3. Ensure wire frame is fully inserted and zip the panel shut.



Assembly of trolley base

1. Locate the baseplate and insert the square metal tubes into the wheel set completely.

The set screw holes in the tubes will only line up properly if tubes are fully inserted.



2. Align holes to ensure proper screw insertion. Locate screws in plastic accompanying unit.

